


MI GUIDE


KJR-120G2 Controller



Hard Wired Controller Quick Guide (KJR-120G2)



- | | |
|--------------|-------------------|
| 1. Mode | 6. Timer |
| 2. Power | 7. Day Off/Del |
| 3. Adjust | 8. Copy/Follow me |
| 4. Fan Speed | 9. Back/Turbo |
| 5. Swing | 10. Confirm |



- | | |
|---|--|
| 1. Operation mode indicator | 8. Turbo/Auxiliary Heat function indicator |
| 2. Fan speed indicator | 9. °C / °F indicator |
| 3. Left-right swing indicator | 10. Temperature display |
| 4. Up-down swing indicator | 11. Lock indicator |
| 5. Faceplate function indicator | 12. Room temperature indicator |
| 6. Main unit and secondary unit indicator | 13. Clock display |
| 7. Follow me function indicator | 14. On/Off timer |
| | 15. Timer display |

Please contact your Midea support team if you have any issues during the installation and commissioning process.

Midea UK Tel: 0191 263 6367